

CS200

POWERING A POLE DISPLAY

1. To power a pole display on a CS200 system, first determine what port the pole display is going to be attached to.
2. Turn the machine over and remove the black plastic cover.
3. To send power to a COM port, you will need to change the following jumper:
 - a. For COM1, move Jumper COM1_9 from 0V to 5V.
 - b. For COM2, move Jumper COM2_9 from 0V to 5V.
 - c. For COM3, move Jumper COM3_9 from 0V to 5V.
 - d. For COM4, move Jumper COM4_9 from 0V to 5V.
4. Close the panel.
5. Attach the pole display and power up the machine.
6. Turn on the pole display.
7. At this point you should have power to the display.